

- **Step 1:** Plug the Roku device into an HDMI port on your TV (HDMI 1, 2, or 3). Select the corresponding input on your TV. Connect the Roku to your Wi-Fi by selecting your SSID and entering the password. Sign into or create a Roku account. The TV will walk you through this step. If you have a Roku TV, proceed to the next step.
- **Step 2:** Press the Home button on the Roku remote, then navigate down to Search. Type in NEMR to find the app.
- **Step 3:** Select the app with our logo (pictured) and click Add App to download it. This can take up to 20 minutes.





Step 4: Once the app is downloaded, open it and enter the Login and Passphrase emailed to you. If you didn't receive it, call our office. After entering the details, click Save, and you're ready to stream!

The People's Court The Acount and the analysis of the analysis					
Nov 12, 12:55 PM 12:9	0 PM 1:00	PM			PM
606 🎎	Days of Our 🚥 🚥	Family Feed	Family Feud		Rachael Ray Today's Show is Ha Sna
608 🕥	Splash and Bubbles Dank's New Triand, Ripple'	Nature Cat. Moth Prolic First, Dane Pr	Let's Go Luna etci O'Drae Dec Her		BlaKidS Learning from Failure
609 🚳	The People's Court Shopping cart catastrophs.	Maury 1 Lied 20 Years Ago DN		•	Tamron Hall
611 🌌	The Bold and the Resultful	The Talk			KELOLAND Living
613 KSFY=	GMA3: Strahan, New Saro & Koke	General Hospital		60	Inside Edition 🔤

<u>Recording (Only if you have NEMR DVR)</u>

Open NEMR TV and navigate to the program you[®] want to record. Highlight it and press the OK button (middle of the arrow buttons) to view the details. Select Record, then choose whether to record new episodes, all episodes, or a one-time recording.

Watch Recordings

In the guide, press the Back button to open options at the top of the screen. Use the right arrow to go to the Recordings tab and press OK. Scroll through your Current Recordings, highlight the program you want to watch, and press Play/Pause to start. If there are multiple recordings, select the one you want and press Play/Pause.



Tip: On the Home Screen, highlight the NEMR App, then press the * button on your remote. Select "Move to Top" to keep the app easily accessible whenever you're on the Home Screen.

Navigating the App Content & Lists

Use the remote circle to navigate left, right, up, or down to highlight items. Press OK to select a highlighted item. Press the Home button to return to the Home Screen, or use the Back button to go to the previous screen.

Watching NEMR TV

From the Home screen, highlight the NEMRTV icon and press the OK button to open the program guide. Use the remote to scroll up or down to a program highlighted in blue; then press Play/Pause to watch it.